

0-360 Panoramic Optic Setup for Fuji FinePix S602 Zoom



- 1) Mount Camera to tripod, with lens pointing vertically.
 - 2) Thread 0-360 Panoramic Optic (with thread adapter) to camera. (Do not overtighten.)
 - 3) Adjust tripod until Optic is vertical (refer to bubble level on top of unit).
 - 4) Turn Power on. Do not open Flash.
 - 5) First time setup: Turn Mode Dial to "SET", and set:
 - ▶ Quality to "6M" and "F (Fine)"
 - ▶ AF MODE to " AF AREA"
 - 6) Turn Mode Dial to "A".
 - 7) Rotate Command Dial until "F11" appears on screen. This is your Aperture (F-stop).
 - 8) Press Menu button and set Self Timer to , ISO to 160, and Photometry to "Spot". Set White Balance to "Auto" (experiment). Also experiment with Sharpness and ISO.
 - 9) Adjust Zoom until image of mirror just fills frame from top to bottom.
- (NOTE: Depending on your camera's threads, the image may be slightly off-center. This is normal.
- A trick is to use a thin piece of paper as a shim between the Optic and adapter to align to center.
- 10) Press Macro button until  appears on screen.
 - 11) Set Auto Focus switch to "AF". Press & Hold AF button while using 4-Direction button to set focus area 2 positions to the right (or left) of center.
 - 12) Press Shutter button halfway to focus. Adjust Zoom again and repeat if necessary.
 - 13) Press the shutter button. You have 10 seconds to hide!



A note about Aperture, Depth of Field, and Field of View

Aperture- a mechanism behind the camera lens similar to the iris of your eye, opening and closing to adjust the amount of light entering the camera. The aperture opening also determines the Depth of Field of the image.

Depth of Field- describes the objects in the image which are in focus, in terms of their distance from the camera. For example, a camera focused at 30m, with a Depth of Field of 8m, will have objects from 26-34m from the camera in focus. Objects closer than 26m or further than 34m will start to become blurry.

Field of View- the vertical Field of View (vFOV) of the 0-360 Panoramic Optic. The 0-360 has a vFOV of 110+ degrees, meaning it will "see" from 50°+ above the horizon to 60°+ below the horizon.

A smaller Aperture opening (higher F-Stop number) allows less light to enter the camera, but yields a higher Depth of Field. With a high F-Stop, the shutter speed needs to be slowed down to allow more light (else a dark photo), but will have more Depth of Field in focus.

A larger Aperture opening (lower F-Stop number) allows more light to enter the camera, but a lower Depth of Field. This means the shutter speed can be faster, but fewer objects will be in focus. (With slower shutter speeds, moving objects may blur.)

The 0-360 is designed to operate with a camera F-Stop of F8.0 or higher (preferably 9 to 11). This provides a high enough Depth of Field to allow the entire mirror to be in focus. With lower F-stops, the shutter speed can be increased, but the upper or lower portions (or both) of the mirror may not be entirely in focus. This means the image far above or far below the horizon may not be sharply focused. This may not be a problem, as many times the sky or the ground may not need to be sharply focused.

With the Fuji FinePix S602 Zoom, you should be able to get a vFOV of approximately 100 degrees, with good focus across the entire image.

For best results, shoot a well-lit scene! With high F-Stops, you need good lighting, or longer exposure times.

Quick Start Guide



Please read the Care Instructions on back page.

IMPORTANT!

Instructions for use with Fuji FinePix S602 Zoom



ENJOY!

The 0-360 Panoramic Optic is warranted against defects in material and workmanship for a period of one year from date of purchase. This warranty does not cover damage caused by accident, abuse, misuse, exposure to the elements, or scratches to the mirror surface. If a defect in workmanship or material is discovered, 0-360.com will, at its option, repair or replace the Optic free of charge. Purchaser must first obtain Return Authorization from 0-360.com, and return the unit properly packaged and freight prepaid. 0-360.com's liability is limited to repair or replacement of the Optic only. This warranty supersedes all other warranties, express or implied.

WARRANTY

- 1) Do not touch, handle, or polish the mirror! While the mirror does have a protective coating, touching or rubbing on its surface can cause scratches. Use the dust blower provided to remove dust before shooting. Use lens cleaning paper or lens cloth only if absolutely necessary, and rub gently. NEVER use a paper towel or other material to clean.
- 2) Avoid dropping or mishandling the unit, as it is a sensitive glass optical device.
- 3) Store the unit in its carrying case when not in use, in an upright position and in a cool, dry environment.
- 4) Use care in threading the Optic into your camera, avoiding cross-threading.

Care Instructions

IMPORTANT!

Thank you for purchasing the 0-360 Panoramic Optic! With proper care and handling, the Optic should give you years of service. Here are a few important handling instructions: